


## SHOWER DRAIN DETAIL

### X-Bond Seamless Stone over concrete substrate

Scale 6"=1'-0"



- X-Bond Seamless Stone
- X-Bond Brown Coat
- Fabric reinforcement encapsulated in X-Bond Brown Coat

1. Strainer
2. Drain head adapter
3. X-Bond Seamless Stone (minimum thickness 1/8"), sloped for proper drainage
4. X-Bond Brown Coat (minimum thickness 1/4"), sloped for proper drainage
5. Fabric reinforcement encapsulated in X-Bond Brown Coat. Applied directly to substrate, over drain flange and clamping collar. Extended 24" radius on substrate around the drain.
6. Concrete substrate
7. Flange
8. Clamping collar
9. Drain base
10. Plumbing waste line



**FLOORS | WALLS | POOL DECKS | WATERPROOFING**  
REDEFINING THE ART OF SURFACE CREATIVITY FOR OVER 25 YEARS USING GREEN MATERIALS